

Nordco CX Hammer Critical Components

Critical for Travel	
Part No.	Description
1605114	Check Valve Cartridge
1623559	Relief Cartridge
1699037	Brake Valve
1699120	Lockup Valve
1699345	Propel Valve
5121046	PLC
5121310	EEPROM (unprogrammed)
5128260	Foot Switch
5128935	Circuit Breaker 10A
5128936	Circuit Breaker 15A
5128937	Circuit Breaker 20A
5128941	Circuit Breaker 30A
5129100	RPC .5A
5129105	RPC 2A
5129110	RPC 4A
5196101	Relay
5196102	Relay
5196105	Relay
10210155	Drive Shaft
17560016	Serpentine Belt
21451405	Motor Mount
22120415	Sprocket Bushing
24266693	Drive Chain
24266695	Drive Chain
28551843	Brake Cylinder
31401840	Junction Box 4 Port
31401860	Junction Box 6 Port
31401880	Junction Box 8 Port
37750013	Unloading Valve
50230093	Propel Motor
59427960	Pump
61231201	Electrical Interlock Relay
61231211	Power Relay
66058006	Clevis
68010027	Brake Cylinder Repair Kit
70900075	Brake Shoe
73045623	Sprocket Bushing
75110480	Drive Sprocket
75110490	Sprocket
90410913	Exchange Axle Assy. 3-7/16"
90411033	Exchange Axle Assy. 3"
22311600-072	DIN Cable
1623560	Cross-over relief
1605114	Make-up check valve

Critical for Spiking Operation	
Part No.	Description
1603868	Spike Load Flow Control
1605992	P.O. Check Valve
1606458	Guide Roller P.R. Valve
1623540	Pressure Reducing Cartridge
1682400	Kick Down Relief Valve
1691101	Joystick Valve
1699084	Spike Load Valve
1699099	Guide Roller Valve
1699333	Gun Valve
1699334	Counterbalance Valve Cartridge
2480325	Stud
3308026	Anvil Retaining Rod Pin
3605351	Jaw Spring
3614365	Anvil Spring
5121048	PLC Extension
5121320	Potentiometer Board
5127415	Prox Switch
7296022	Diaphragm Assy.
10061016	Ball Screw Actuator
10560043	Anvil
14382490	Guide Rod, Chrome
21440150	Prox Switch Bracket
22034755	Guide Rod Bushing
22034755	Guide Rod Bushing, Bronze
22043123	Bushing
26600610	Controller
28550006	Feed Cylinder
28550116	Guide Roller Cylinder
28550117	Spotting Cylinder
28550255	Gun Up/Down Cylinder
28552672	Pusher Cylinder
32356300	Adapter Flange
33920067	RH Guide Support
33920068	LH Guide Support
46650032	Spike Jaw LH 5/8" Straight
46650033	Spike Jaw RH 5/8" Straight
46650050	Spike Jaw LH Wide Slot
46650051	Spike Jaw RH Wide Slot
46650062	Spike Jaw LH Lewis
46650063	Spike Jaw RH Lewis
50211530	Fan/Motor Assy.
50230090	Vibrator Motor
54239957	Jaw Pin
60570039	Oil Cooler
65630100	Guide Rod, Stainless
66062630	Rod Eye
68010016	Feed Cylinder Seal Kit
73034100	Standard Anvil Sleeve
73034101	Curve Block Anvil Sleeve
75760137	LH Escapement Cam
75760138	RH Escapement Cam
82090093	RH Tray Head
82090094	LH Tray Head
82090098	RH Lewis Bolt Tray Head
82090099	LH Lewis Tray Head
82090101	RH Oversized Tray Head
82090102	LH Oversized Tray Head
96090308	Gun Cylinder Repair Kit
96350798	Cylinder Repair Kit
96410050	Foot Switch Harness
96410265	Controller Cable
96410474	Washer Stack
96411239	LH Pusher Block Kit
98400003	Lewis Pusher Block Kit
98410248	Fan Kit
98411240	RH Pusher Block Kit
22311601-084	Prox Switch Cable

Critical for Nipper Operation	
Part No.	Description
1698950	Nipper Cylinder Lock Valve
1698960	Nipper P.R. Cartridge
1699304	Nipper Lock Valve Cartridge
1699338	Nipper Up/Down Valve
1699339	Nipper Hook Valve
13120701	Keyhole Retaining Plate
28551795	Nipper Hook Cylinder
28552747	Nipper Cylinder
44044340	Nipper Hook
54007502	Nipper Pin
54266875	Nipper Hook Pin
96410664	Hook Cylinder Repair Kit
96412746	Nipper Cylinder Repair Kit

Critical for Gager Operation	
Part No.	Description
5397150	Cam Follower Bearing
8074030	Gager Wheel
22048025	Bushing
22120405	Bushing, Nylon
22150281	Bushing
22150286	Bushing
22311032	Gager Buggy Cable
26607770	LVDT
28553743	Gager Cylinder
59050017	LVDT Probe
66216156	Gager Guide Roller
66219001	Gager Roller
86107590	Insulating washer
96410185	Gager Cylinder Repair Kit

IMPORTANT NOTE: These are general recommendations. Parts may vary based on the model and configuration of your machine. Consult Nordco Parts at 1-800-647-1724 for more information.



Service from the Ground Up®

1-800-647-1724
www.nordco.com

© Nordco Inc. October 2010