

Nordco M7 Ballast Regulator/Snow Fighter  
Critical Components (S/N 800300 - 800405)

Part Number	Description
500650	Implement/Broom Pump (complete)
500626	Implement Pump only
500627	Broom Pump only
54218493	Pump Unloading Valve
F-233	Snow Screw Motor
500028	Broom Motor
500629	Snow Blower Directional Valve
500803	Snow Blower Needle Valve
500430-24V	Plow Float Valve
1604900	Flow Control Valve
500175	6-Station Manifold Assembly D03
500615	Brake Solenoid Valve
750240	Brake Cylinder
500768	Brake De-ice Valve
500746	Brake Foot Valve
500011	Transmission Charge Pump (800300 only)
500777	Transmission Charge Pump (800301+ only)
500431	Charge Pump Relief Valve
500649	Travel Pump
500648	Travel Motor
520209	Operator's Joystick Control
460311	Axle Assembly
70900080	Brake Shoe
21800099	Brake Head Bracket
3626150	Brake Spring
802303	Brake Shoe Pin
580044	Front Drive Shaft
580052	Rear Drive Shaft
580051	Intermediate Drive Shaft
700455	Shaft Bearing
500383	Oil Cooler Core
500384	Oil Cooler Fan/Motor
7500-120	Plow Cylinder
810491	Plow Cylinder Pivot Pin
7500-227	Plow Lift Cylinder
7500-64	Broom Tilt Cylinder
7500-109	Broom Lift Cylinder
750299	Snow Wing Tilt Up/Down Cylinder
700182	Tilt Cylinder Cap End Pin
700283	Tilt Cylinder Rod End Pin
7500-101	Snow Wing In/Out Cylinder
B-4704-10	Snow Wing In/Out Cylinder Pin
750247	Snow Wing Tilt Cylinder
700384	Tilt Cylinder Pin
700383	Lock Pin
A-25470	Pivot Pin
5127411	Prox Switch
22311601-060	Prox Switch Cable
4539-68	Chain
4539-70	Chain
C-33863	Drive Sprocket
B-33860	Auger Sprocket
C-10346	Blower Sprocket
C-33138	Propeller Blade
61231211	Main Power Relay
520234	EDC
B-40588	Lower Pivot Pin

**IMPORTANT NOTE:** These are general recommendations. Parts may vary based on the model and configuration of your machine. Consult Nordco Parts at 1-800-647-1724 for more information.



Service from the Ground Up®

1-800-647-1724

[www.nordco.com](http://www.nordco.com)

© Nordco Inc. October 2010