

Nordco Machine Spare Parts



Auto-Life Model LS Basic Spare Parts Package

The Nordco Auto-Lift Model LS Basic Spare Parts Package includes high wear and critical components needed to keep your machine in top working condition, and back in service as quickly as possible.



SPLSAL01B Basic Spare Parts Package - Insulated Roller Clamp Arm

SPLSAL01B Basic Spare Parts Package - Non-Insulated Roller Clamp Arm

SPLSAL01B

QTY	PART #	DESCRIPTION
1	96790134	ASSY,PLATE PUSHER
1	87128945	CORD ASSY PUSHER PLATE
2	28552501	CYLINDER,2.50 DIA 6.00 STROKE
2	28552671	CYLINDER,3.00 DIA 14.1 STROKE
1	98790018	KIT,ROLLER CLAMP ARM INSULATED



SPLSAL02B

QTY	PART #	DESCRIPTION
1	96790134	ASSY,PLATE PUSHER
1	87128945	CORD ASSY PUSHER PLATE
2	28552501	CYLINDER,2.50 DIA 6.00 STROKE
2	28552671	CYLINDER,3.00 DIA 14.1 STROKE
1	98790017	KIT,ROLLER CLAMP ARM NON-INSUL

Nordco Parts
800-647-1724

Nordco
245 W Forest Hill Ave.
Oak Creek, WI 53154 USA
Phone: 414-766-2180
Fax: 414-766-2379
www.nordco.com