

Product Support Bulletin 2007-012

245 W. Forest Hill Avenue Oak Creek, WI 53154

Contact: Gary D. Van Deluyster, Service Manager - Phone: 800-445-9258 - Fax: 414-766-2266

Maintenance of Way ~ Work Equipment Bulletin

DATE:	November 17, 2007		
SUBJECT:	Defective Aluminum Turntable Base Recall – 15138881		
RATING:	X DIREC	CTIVE n is required)	ALERT (Potential Problem)
		RMATION n is optional)	(Enhance Product)
MACHINE MODEL(S):		CX Hammer Anchor Applicator Model F	
SERIAL NUMBER(S):		All machines with Aluminum Turntable Bases	
SUMMARY:		The Aluminum Turntable Bases, p/n 15138881, supplied in 2007 have insufficient welds on the center tube support gussets and are being recalled. See Figure 1 on Page 2. The defective Aluminum Turntable Bases have intermittently stitch-welded gussets as shown in Figure 2 on Page 2. Any Aluminum Turntable Bases with stitch-welded gussets, either supplied with machines or ordered as repair parts, are being recalled.	
OPERATIONAL IMPACT:		THESE ALUMINUM TURNTABLE BASES MAY FAIL WHILE LIFTING THE MACHINE, POSSIBLY RESULTING IN SEVERE INJURY OR DEATH.	
ACTION:		WELDED GUSSETS AND R TURNTABLE BASES FROM ATTEMPT TO REPAIR DEF FIELD.	ECTIVE TURNTABLE BASES IN THE
		Only aluminum turntable base	s with stitch-welded gussets are affected

Only aluminum turntable bases with stitch-welded gussets are affected by this recall and must be returned to Nordco for replacement. Aluminum Turntable Bases with continuous welded gussets and Steel Turntable Bases are not affected by this recall.



WARRANTY: Aluminum Turntable Bases with stitch-welded gussets will be replaced under warranty. Contact the Nordco Service Department at 1-800-445-9258 to obtain a Goods Return number (GRFC). Please have the serial number of the machine(s) available when calling or the purchase order number in the case of replacement bases. Do not return any bases to Nordco without first obtaining a GRFC number.




Figure 1 Aluminum Turntable Base p/n 15138881




Figure 2